

# GiM CIU

Installation and operating instructions



be  
think  
innovate

GRUNDFOS



# GiM CIU

---

<b>English (GB)</b>	
Installation and operating instructions . . . . .	4
<b>Appendix A . . . . .</b>	<b>15</b>
<b>Appendix B . . . . .</b>	<b>17</b>
<b>Declaration of conformity . . . . .</b>	<b>18</b>

# English (GB) Installation and operating instructions

## Original installation and operating instructions

### Table of contents

<b>1.</b>	<b>General information . . . . .</b>	<b>4</b>
1.1	Hazard statements . . . . .	4
1.2	Notes . . . . .	4
<b>2.</b>	<b>Product introduction . . . . .</b>	<b>5</b>
2.1	Product description . . . . .	5
2.2	Intended use . . . . .	5
2.3	Applications . . . . .	5
2.4	LEDs . . . . .	5
2.5	Identification. . . . .	5
<b>3.</b>	<b>Receiving the product. . . . .</b>	<b>6</b>
3.1	Inspecting the product . . . . .	6
3.2	Scope of delivery . . . . .	6
<b>4.</b>	<b>Installation requirements . . . . .</b>	<b>6</b>
4.1	Location . . . . .	6
4.2	Radio frequency radiation exposure, for Canada and US only . . . . .	6
<b>5.</b>	<b>Mechanical installation . . . . .</b>	<b>7</b>
5.1	Mounting on the wall . . . . .	7
<b>6.</b>	<b>Electrical connection . . . . .</b>	<b>7</b>
6.1	Terminals . . . . .	9
6.2	Connecting the power supply. . . . .	9
6.3	Connecting GENIbus to the pump . . . . .	10
6.4	Sensor cable . . . . .	10
6.5	Connecting the IO connections. . . . .	12
<b>7.</b>	<b>Starting up the product . . . . .</b>	<b>13</b>
7.1	Connecting the unit to Grundfos GO Remote 2.0 . . . . .	13
<b>8.</b>	<b>Servicing the product . . . . .</b>	<b>13</b>
8.1	Cleaning the product . . . . .	13
<b>9.</b>	<b>Technical data . . . . .</b>	<b>13</b>
<b>10.</b>	<b>Disposing of the product . . . . .</b>	<b>14</b>

## 1. General information



Read this document before you install the product. Installation and operation must comply with local regulations and accepted codes of good practice.

Read the installation and operating instructions for the relevant CLM module.

### 1.1 Hazard statements

The symbols and hazard statements below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.



#### DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.



#### WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.



#### CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The hazard statements are structured in the following way:



#### SIGNAL WORD

#### Description of the hazard

Consequence of ignoring the warning

- Action to avoid the hazard.

### 1.2 Notes

The symbols and notes below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.



Observe these instructions for explosion-proof products.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



Tips and advice that make the work easier.

## 2. Product introduction

### 2.1 Product description

The product monitors the activity of a Grundfos CR, CRE pump. It detects possible irregularities concerning CR, CRE pumps to increase system uptime and keep service and maintenance people on track with pump operation and status for maintenance planning.

GRUNDFOS iSOLUTIONS MONITOR is referred to as "GiM CIU" in this document.

### 2.2 Intended use

The product is intended for use with a Grundfos CR, CRE pump. It can be used for monitoring the pump but not for controlling it.

### 2.3 Applications

The product is used as a communication interface between a Grundfos product and a main network. It is used together with a CIM module (CIM = Communication Interface Module) fitted in the unit. GENIBus is optional communication between the unit and a Grundfos product.

### 2.4 LEDs

The three LEDs are placed on the front cover of the GiM CIU. The Bluetooth button is placed on the bottom on one of the cable glands.


#### Explanation of the symbols

Symbol	Description
	Red and green status LED for the main network. See the installation and operating instructions for the CIM module for more information.
	Status LED for the internal communication between the CIM module and the Grundfos product. See the installation and operating instructions for the CIM module for more information.
<b>STATUS</b>	Monitor status. See the following table for descriptions.
	Bluetooth button for pairing between GiM CIU and Grundfos GO Remote 2.0.

STATUS LED	Description
Permanently green	The system is working.
Flashing green	GiM CIU is in learning mode.
Permanently yellow	A warning from the CR pump, for example, high media temperature, vibration or cavitation. It could also be a warning indicating, for example, a VTU sensor fault or missing power for the real-time clock.
Permanently red	An alarm from the CR pump, for example, dry run, high media temperature, vibration or cavitation.

### 2.5 Identification

#### 2.5.1 Nameplate



TM00971

#### Example of a nameplate

Pos.	Description
1	Type designation
2	Product number
3	Supply voltage
4	Version number
5	Production code (year and week)
6	Serial number
7	Enclosure class
8	FCC and IC text, only for UL variants
9	Environmental type
10	Rated power
11	Production site
12	Markings and approvals

## Related information

### [4.1 Location](#)

## 3. Receiving the product

### 3.1 Inspecting the product

Before installing the product, do the following:

1. Check that the product is as ordered.
2. Check that no visible parts have been damaged.
3. If parts are damaged or missing, contact your local Grundfos sales company.

### 3.2 Scope of delivery

The packaging contains the following items:

- GRUNDFOS iSOLUTIONS MONITOR CIU unit (GIM CIU)
- installation and operating instructions for the product.

## 4. Installation requirements

### 4.1 Location

Install the product in a location that meets the following requirements:

- Place the product in a flood-safe place.
- Make sure that the ambient temperature is within the limits.
- Install the product as close as possible to the connected pumps, sensors, and accessories.
- The product must be easily accessible.
- You must install the product in a protective shed or enclosure to avoid direct sunlight and rain.
- Indoor installation: The product must be installed in a well-ventilated room to ensure cooling of its components.

## Related information

### [2.5.1 Nameplate](#)

### [9. Technical data](#)

## 4.2 Radio frequency radiation exposure, for Canada and US only

This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated with a minimum distance of 20 cm (0.66 feet) between the radiator and your body.

FCC ID: OG3-GIM1A

IC: 10447A-GIM1A

## 5. Mechanical installation

### 5.1 Mounting on the wall

Mount the unit on a surface. The cable glands must face downwards.



#### CAUTION


##### The product can fall down

Minor or moderate personal injury

- Make sure to use screws that fit into the unit and support its weight.
- All cable screens must be connected to earth. If it is not possible to use cable clamps, the stripped part of the cable screen must be as short as possible to reduce the impedance at high frequencies.
- The cable glands must face downwards.



1. Loosen the screws and remove the front cover.
2. Drill holes in the surface.



TM070502

Pos.	Dimensions [mm] (inch)
------	------------------------

1	115 (4.53")
---	-------------

2	91 (3.58")
---	------------

3	ø4.5 (0.18")
---	--------------

4	81.5 (3.21")
---	--------------

3. Insert wall plugs, if applicable.
4. Fit the four screws in the mounting holes and cross-tighten the screws, 1.25 Nm.

## 6. Electrical connection

#### DANGER

##### Electric shock

Death or serious personal injury

- Applies to supply voltages above 30 VRMS / 60 VDC: The installation must incorporate a switch or a circuit breaker in order to switch off the mains supply. It must be close to the CIU unit and easily accessible for the operator. It must be marked as a disconnecting device for the CIU unit.
- In case of an insulation fault, the fault current may be a pulsating DC. Observe national legislation about requirements for and selection of a Residual Current Device (RCD) when installing the pump.

The residual-current circuit breaker must be marked like this:



TM070502

**WARNING****Electric shock**

Death or serious personal injury

- Switch off the power supply before making any electrical connections. Make sure that the power supply cannot be switched on accidentally.
- The protective earth from the socket outlet must be connected to the protective earth in the pump. Therefore, the applied plug must have the same protective earth connection systems as the socket outlet, or a suitable adapter must be applied.
- Ensure that the high-voltage protection cover is mounted correctly once the installation is finished.
- Tighten the cable glands securely to avoid water coming into the unit or the cables being pulled out.
- The CIU unit and GENibus must only be connected to SELV or SELV-E circuits.

**WARNING****Falling off ladder**

Death or serious personal injury

- Take care when installing the unit on the pump.


**CAUTION****Hot surface**

Minor or moderate personal injury

- Do not touch the pump. The surface may be hot.



All installation work must only be carried out by qualified and authorised persons.



Pos.	Description
1	CIM connection
2	IO connections
3	GENibus master, connection to the pump
4	VTU board
5	Sensor connections
6	Power supply
7	High-voltage protection cover

**Related information**

[6.2 Connecting the power supply](#)

[6.3 Connecting GENibus to the pump](#)


[6.4.1 Mounting the sensor cable](#)

[6.5 Connecting the IO connections](#)

## 6.1 Terminals



Remember to tighten the cable glands before you switch on the power.  
The tightening torque is 1.5 Nm.



TK077411

### Pos. Description

1	Blank (default) Options: antenna, Ethernet or IO
2	Blank (default) Options: antenna, Ethernet or IO
3	Blank (default) Options: GENIbus master (pump) or IO
4	VTU sensor
5	Power supply
6	Bluetooth connect button

## 6.2 Connecting the power supply


### WARNING

#### Electric shock


Death or serious personal injury

- Make sure there is proper insulation around the supply cable.
- The protective earth wire must be longer than the neutral and phase wires.

1. Remove the front cover.
2. Remove the sensor connector and the IO connections.
3. Pull the high-voltage protection cover upwards to access the connectors.
4. Lead the supply cable through the cable gland.
5. Connect the supply conductors to earth, N and L.
6. Tighten the cable glands.
7. Fit the high-voltage protection cover again.



TK077422




TK077423

*Push the cover down firmly*

8. Fit the front cover.


**Example:**



TAK07416

*Electrical connection***Pos. Description**

- |   |                           |
|---|---------------------------|
| 1 | Protective earth terminal |
| 2 | Neutral terminal          |
| 3 | Phase terminal            |




TAK077743

*Wire requirements***Related information**

- [6. Electrical connection](#)
- [6.3 Connecting GENIbus to the pump](#)
- [6.5 Connecting the IO connections](#)

**6.3 Connecting GENIbus to the pump**

1. Remove the front cover.
2. Lead the GENIbus cable through the cable gland.
3. Connect the conductors to terminals A, Y and B.
4. Connect the cable screen under the earth clamp, and tighten the earth clamp.
5. Tighten the cable gland.
6. Fit the front cover.

**Example:**

TAK079415

*GENIbus connection***Pos. Designation Description**

- |   |   |   |
|---|---|---|
| 1 | A | GENIbus terminal A. Positive data signal. |
| 2 | Y | GENIbus terminal Y                        |
| 3 | B | GENIbus terminal B. Negative data signal. |
| 4 | - | Earth clamp                               |

**Related information**

- [6. Electrical connection](#)
- [6.2 Connecting the power supply](#)

**6.4 Sensor cable****WARNING****Fall hazard**

- Death or serious personal injury
- Follow local working environment regulations.



**6.4.1 Mounting the sensor cable**

1. Read the GIM quick guide to see how to mount the sensor cable.



OR09801208

[net.grundfos.com/qr/i/99802939](http://net.grundfos.com/qr/i/99802939)



TA070457

Pos.	Colour	Designation	Description
1	White	DR	Dry run
2	Brown	V+	Supply
3	Green	GND	Ground
4	Yellow	Rw1	Pt100
5	Grey	Rw2	Pt100
6	Pink	Vin	Analog
7	Blue	GND	Ground
8	Red	GND	Ground

For more information on the VTU sensor, see the data sheet.



QR9873130

[net.grundfos.com/qr/i/99873130](http://net.grundfos.com/qr/i/99873130)

## Related information

### [6. Electrical connection](#)


## 6.5 Connecting the IO connections

### WARNING

#### Electric shock

Death or serious personal injury

- The IO connections of the GIM CIU unit must be connected to SELV or SELV-E circuits only.



TAK70438

### Wiring diagram

### Options for configuration of connections

Electrical signals	DI	AI/DI 1	AI/DI 2	AI/DI 3	Pt100(0)
Digital input	x				
Analog input, 0 - 20 mA		x	x	x	
Analog input, 4 - 20 mA	x		x	x	
Analog input, 0 - 10 V	x		x	x	
Analog input, 0 - 5 V	x		x	x	
Analog input, 0.5 - 3.5 V	x		x	x	
Pt100					x
Pt1000					x

### Related information

#### 6. Electrical connection

#### 6.2 Connecting the power supply

## 7. Starting up the product

### 7.1 Connecting the unit to Grundfos GO Remote 2.0

Before connecting the product, the Grundfos GO Remote 2.0 app must be downloaded to your smartphone or tablet. The app is free of charge and available for iOS and Android devices.

#### CAUTION

##### Radiation

Minor or moderate personal injury

- Human tissue may be heated by RF energy. Locate the antenna at a minimum distance of 20 cm (7.87 inches) from any body parts.

1. Open Grundfos GO Remote 2.0 on your device. Make sure that Bluetooth is enabled.  
Your device must be within reach of the product to establish Bluetooth connection.
2. Press the connect icon in Grundfos GO Remote 2.0.
3. Press the connect button on the product. The blue LED is flashing until your device is connected. Once the connection is established, the LED is permanently on.  
Grundfos GO Remote 2.0 is now loading the data for the product.
4. Refer to the GIM quick guide for further information regarding startup.



QR99802939

[net.grundfos.com/qr/i/99802939](http://net.grundfos.com/qr/i/99802939)

## 8. Servicing the product

The product cannot be serviced.

- Contact Grundfos. If the product is faulty, it must be replaced.

### 8.1 Cleaning the product

The product must only be cleaned with a clean dry or a soapy damp cloth.

## 9. Technical data

### Electrical supply

Transient overvoltage	Category II
Supply voltage	24-240 VAC/VDC, ± 10 %
Frequency	DC, 50/60 Hz
Max. power consumption	11 W

### Cables

Power supply cable	IEC: 0.75 - 4 mm <sup>2</sup> UL: 18 - 12 AWG Use a 3-core cable that meets the requirements of the National Electric Code.
	 Use copper or copper-clad aluminum conductors only. Use a power cable with an outer diameter of ø6 - 10 mm only.
Recommended communication cable	Screened, double twisted-pair Cross-section: 0.2 - 0.3 mm <sup>2</sup> AWG: 24 - 22 Maximum cable length: 1200 m (4000 ft) Use a communication cable with an outer diameter of ø4 - 10 mm.
Cable entry	5 x M16 ø3.5 - 10 mm clamping range

**Fuses**

<b>Back-up fuse</b>	Maximum 10 A. Both standard fuses as well as quick- and slow-blow fuses are suitable.
<b>Short-circuit protection</b>	Use fuses that comply with IEC 60127. USA and Canada (branch circuit protection): Use a UL/CSA listed non-time delay (high capacity) fuse that complies with the UL248 series or an inverse time circuit breaker that complies with UL489. Fuse types RK1, RK5, J, and CC are acceptable.

**GENIbus master, for pump connection**

Transceiver	RS-485
Protocol	GENIbus
Parity	None
Stop bits	1
Transmission speed	9600 bit/s

**GENIbus connection, for Grundfos GO Remote PC**

Transceiver	RS-485
Protocol	GENIbus
Parity	None
Stop bits	1
Transmission speed	9600 (default), 19200, 38400, 115200 bit/s

**Modbus RTU**

Transceiver	RS-485
Protocol	Modbus
Parity	None, odd, even (default)
Stop bits	1 (default), 2
Modbus address	1-247. Default: 247.
Transmission speed	9600 (default), 19200, 38400 bit/s

**Environmental conditions**

Max. altitude above sea level	2000 m (6562 ft)
Relative humidity	95 %, non-condensing
Pollution degree	Category 3
Enclosure class	IP54 according to IEC 60529 Type 2 according to UL 50 For indoor use only.

**Ambient temperature**

During operation	-20 to +45 °C (-4 to +113 °F)
During storage	-20 to +60 °C (-4 to +140 °F)
During transport	-20 to +60 °C (-4 to +140 °F)

**Related information***4.1 Location***10. Disposing of the product**

This product or parts of it must be disposed of in an environmentally sound way.

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.



The crossed-out wheelie bin symbol on a product means that it must be disposed of separately from household waste. When a product marked with this symbol reaches its end of life, take it to a collection point designated by the local waste disposal authorities.

The separate collection and recycling of such products will help protect the environment and human health.

See also end-of-life information at [www.grundfos.com/product-recycling](http://www.grundfos.com/product-recycling).

## Appendix A

---

### A.1. FCC/ISED general requirements

This device complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This device must be installed and operated with a minimum distance of 20 cm (7.87 inches) between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

#### FCC



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.



Changes or modifications made to this equipment not expressly approved by Grundfos may void the user's authority to operate this equipment.

#### ISED



This device complies with ISED's license-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.



Changes or modifications made to this equipment not expressly approved by Grundfos may void the user's authority to operate this equipment.

This radio transmitter (IC: 10447A-GIM1A) has been approved by ISED to operate with Grundfos cellular module CIM 280-US (IC: 10447A-CIM2X034G). Only the original Grundfos supplied antenna, part no. 99838775, is permitted.

The maximum antenna gain is:

CDMA850/LTE B5	+0.3 dBi (824-849 MHz)
CDMA1900/LTE B2	-1.2 dBi (1850-1910 MHz)
LTE B4	+1.5 dBi (1710-1755 MHz)
LTE B17	-7.0 dBi (704-716 MHz)
LTE B12	-7.0 dBi (698-716 MHz)
LTE B13	-5.0 dBi (777-787 MHz)

#### Bluetooth information

Frequency of operation	2400 – 2483.5 MHz (ISM band)
Modulation type	GFSK
Data rate	1 Mbps
Transmit power	5 dBm EIRP with internal antenna

### A.2. Exposition aux radiations de fréquence radio

Cet appareil est conforme aux limites FCC et ISED d'exposition aux radiations qui ont été définies pour un environnement non contrôlé. Cet appareil doit être installé et fonctionner à une distance d'au moins 20 cm (7.87 in) du radiateur et de votre corps. Il ne doit ni se situer, ni fonctionner conjointement avec une autre antenne ou un autre émetteur.

Cet appareil est conforme au paragraphe 15 des règlements du FCC et aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.



L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



Toute modification apportée à cet appareil n'étant pas explicitement approuvée par Grundfos peut annuler l'autorisation du FCC à faire fonctionner cet appareil.

### Informations Bluetooth

Fréquence de fonctionnement	2400 - 2483,5 MHz (bande ISM)
Type de modulation	GFSK
Débit de données	1 Mbps
Puissance de transmission	PIRE 5 dBm avec antenne interne

## Appendix B

### B.1. China RoHS, table C

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr6+)	多溴联苯 (PBB)	多溴联苯醚 (PBDE)
印刷电路板	X	O	O	O	O	O
紧固件	X	O	O	O	O	O

本表格依据 SJ/T 11364 的规定编制

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 该规定的限量要求。



该产品环保使用期限为 10 年，标识如左图所示。

此环保期限只适用于产品在安装与使用说明书中所规定的条件下工作

## Declaration of conformity

### **GB: EU declaration of conformity**

We, Grundfos, declare under our sole responsibility that the product GiM CIU, to which the declaration below relates, is in conformity with the Council Directives listed below on the approximation of the laws of the EU member states.

### **CZ: Prohlášení o shodě EU**

My firma Grundfos prohlašujeme na svou plnou odpovědnost, že výrobek GiM CIU, na který se toto prohlášení vztahuje, je v souladu s níže uvedenými ustanoveními směrnice Rady pro sbližení právních předpisů členských států Evropského společenství.

### **DK: EU-overensstemmelseserklæring**

Vi, Grundfos, erklærer under ansvar at produktet GiM CIU som erklæringen nedenfor omhandler, er i overensstemmelse med Rådets direktiver der er nævnt nedenfor, om indbyrdes tilnærmelse til EU-medlemsstaterne lovgivning.

### **ES: Declaración de conformidad de la UE**

Grundfos declara, bajo su exclusiva responsabilidad, que el producto GiM CIU al que hace referencia la siguiente declaración cumple lo establecido por las siguientes Directivas del Consejo sobre la aproximación de las legislaciones de los Estados miembros de la UE.

### **FR: Déclaration de conformité UE**

Nous, Grundfos, déclarons sous notre seule responsabilité, que le produit GiM CIU, auquel se réfère cette déclaration, est conforme aux Directives du Conseil concernant le rapprochement des législations des États membres UE relatives aux normes énoncées ci-dessous.

### **HR: EU deklaracija sukladnosti**

Mi, Grundfos, izjavljujemo s punom odgovornošću da je proizvod GiM CIU, na koja se izjava odnosi u nastavku, u skladu s dolje navedenim direktivama Vijeća o usklađivanju zakona država članica EU-a.

### **IT: Dichiarazione di conformità UE**

Grundfos dichiara sotto la sua esclusiva responsabilità che il prodotto GiM CIU, al quale si riferisce questa dichiarazione, è conforme alle seguenti direttive del Consiglio riguardanti il riavvicinamento delle legislazioni degli Stati membri UE.

### **BG: Декларация за съответствие на ЕО**

Ние, фирма Grundfos, заявяваме с пълна отговорност, че продуктът GiM CIU, за който се отнася настоящата декларация, отговаря на следните директиви на Съвета за уеднаквяване на правните разпоредби на държавите-членки на ЕО.

### **DE: EU-Konformitätserklärung**

Wir, Grundfos, erklären in alleiniger Verantwortung, dass das Produkt GiM CIU, auf das sich diese Erklärung bezieht, mit den folgenden Richtlinien des Rates zur Angleichung der Rechtsvorschriften der EU-Mitgliedsstaaten übereinstimmt.

### **EE: EÜvastavusdeklaratsioon**

Meie, Grundfos, kinnitame ja kanname ainuisikulist vastutust selle eest, et toode GiM CIU, mille kohta all olev deklaratsioon käib, on kooskõlas Nõukogu Direktiividega, mis on nimetatud all pool vastavalt vastuvõetud õigusaktide ühtlustamise kohta EÜ liikmesriikides.

### **FI: EU-vatimustenmukaisuusvakuutus**

Grundfos vakuuttaa omalla vastuullaan, että tuote GiM CIU, jota tämä vakuutus koskee, on EU:n jäsenvaltioiden lainsäädännön lähetätämisseen tähänäviin Euroopan neuvoston direktiivien vaatimusten mukainen seuraavasti.

### **GR: Δήλωση συμμόρφωσης ΕΕ**

Εμείς, η Grundfos, δηλώνουμε με αποκλειστικά δική μας ευθύνη ότι το προϊόν GiM CIU, στο οποίο αναφέρεται η παρακάτω δήλωση, συμμορφώνεται με τις παρακάτω Οδηγίες του Συμβουλίου περί προσέγγισης των νομοθεσιών των κρατών μελών της ΕΕ.

### **HU: EU megfelelőségi nyilatkozat**

Mi, a Grundfos vállalat, teljes felelősséggel kijelentjük, hogy a(z) GiM CIU termék, amelyre az alábbi nyilatkozat vonatkozik, megfelel az Európai Unió tagállamainak jogi irányelvét összehangoló tanács alábbi előírásainak.

### **LT: ES atitikties deklaracija**

Mes, Grundfos, su visa atsakomybe pareiškiame, kad produktas GiM CIU, kuriam skirta ši deklaracija, atitinka žemiau nurodytas Tarybos Direktyvas dėl ES šalių narių įstatymų suderinimo.

**LV: ES atbilstības deklarācija**

Sabiedrība Grundfos ar pilnu atbildību paziņo, ka produkts GiM CIU, uz kuru attiecas tālāk redzamā deklarācija, atbilst tālāk norādītajām Padomes direktīvām par ES dalībvalstu normatīvo aktu tuvināšanu.

**PL: Deklaracja zgodności UE**

My, Grundfos, oświadczamy z pełną odpowiedzialnością, że nasz produkt GiM CIU, którego deklaracja niniejsza dotyczy, jest zgodny z następującymi dyrektywami Rady w sprawie zbliżenia przepisów prawnych państw członkowskich.

**RO: Declarația de conformitate UE**

Noi Grundfos declarăm pe propria răspundere că produsul GiM CIU, la care se referă această declarație, este în conformitate cu Directivelor de Consiliu specificate mai jos privind armonizarea legilor statelor membre UE.

**RU: Декларация о соответствии нормам ЕС**

Мы, компания Grundfos, со всей ответственностью заявляем, что изделие GiM CIU, к которому относится нижеприведённая декларация, соответствует нижеприведённым директивам Совета Европы о тюдественности законов стран-членов ЕС.

**SI: Izjava o skladnosti EU**

V Grundfusu s polno odgovornostjo izjavljamo, da je izdelek GiM CIU, na katerega se spodnja izjava nanaša, v skladu s spodnjimi direktivami Sveta o približevanju zakonodaje za izenačevanje pravnih predpisov držav članic EU.

**TR: AB uygunluk bildirgesi**

Grundfos olarak, aşağıdaki bildirim konusu olan GiM CIU ürünlerinin, AB üye ülkelerinin direktiflerinin yaklaştırılmasıyla ilgili durumun aşağıdaki Konsey Direktifleriyle uyumlu olduğunu ve bununla ilgili olarak tüm sorumluluğun bize ait olduğunu beyan ederiz.

**CN: 欧盟符合性声明**

我们，格兰富，在我们的全权责任下声明，产品 GiM CIU 系列，其制造和性能完全符合以下所列欧盟委员会指令。

**NL: EU-conformiteitsverklaring**

Wij, Grundfos, verklaren geheel onder eigen verantwoordelijkheid dat product GiM CIU, waarop de onderstaande verklaring betrekking heeft, in overeenstemming is met de onderstaande Richtlijnen van de Raad inzake de onderlinge aanpassing van de wetgeving van de EU-lidstaten.

**PT: Declaração de conformidade UE**

A Grundfos declara sob sua única responsabilidade que o produto GiM CIU, ao qual diz respeito a declaração abaixo, está em conformidade com as Directivas do Conselho sobre a aproximação das legislações dos Estados Membros da UE.

**RS: Deklaracija o usklađenosti EU**

Mi, kompanija Grundfos, izjavljujemo pod punom vlastitom odgovornošću da je proizvod GiM CIU, na koji se odnosi deklaracija ispod, u skladu sa dole prikazanim direktivama Saveta za usklađivanje zakona država članica EU.

**SE: EU-försäkran om överensstämmelse**

Vi, Grundfos, försäkrar under ansvar att produkten GiM CIU, som omfattas av nedanstående försäkran, är i överensstämmelse med de rådsdirektiv om inbördes närmande till EU-medlemsstaternas lagstiftning som listas nedan.

**SK: ES vyhlásenie o zhode**

My, spoločnosť Grundfos, vyhlasujeme na svoju plnú zodpovednosť, že produkt GiM CIU, na ktorý sa vyhlásenie uvedené nižšie vzťahuje, je v súlade s ustanoveniami nižšie uvedených smerníc Rady pre zblíženie právnych predpisov členských štátov EÚ.

**UA: Декларація відповідності директивам ЄС**

Ми, компанія Grundfos, під нашу одноосібну відповідальність заявляємо, що виріб GiM CIU, до якого відноситься нижче наведена декларація, відповідає директивам ЄС, переліченим нижче, щодо тотожності законів країн-членів ЄС.

**NO: EU:s samsvarsærklæring**

Vi, Grundfos, erklærer under vårt eneansvar at produktet GiM CIU, som denne erklæringen gjelder, er i samsvar med Det europeiske råds direktiver om tilnærming av forordninger i EU-landene.

**AR: اقرار مطابقة الاتحاد الأوروبي (EU)**

نقر نحن، جروندفوس، ممكنتي مسؤوليتنا الفردية بن المنتج GiM CIU، الذي يختص به الإقرار أدناه، يكون مطابقاً لتربيات المجلس المنكورة أدناه بشأن التقارب بين قوانين الدول أعضاء الاتحاد الأوروبي .(EU)

- Radio Equipment Directive 2014/53/EU.  
Standards used:  
EN 61010-1:2010  
EN 301 489-1 ver. 2.2.0  
EN 301 489-17 ver. 3.2.4  
EN 301 489-52 ver. 1.3.1  
EN 301 908-1 ver. 11.1.1  
EN 301 908-2 ver. 1.1.2  
EN 301 908-13 ver. 11.1.2  
EN 301 511 ver. 12.5.1  
EN 300 328 ver. 2.2.0
- RoHS 2 Directives (2011/65/EU and 2015/863/EU).  
Standard used:  
EN IEC 63000:2018

This EC declaration of conformity is only valid when published as part of the Grundfos installation and operating instructions (publication number 99802941).

Bjerringbro, 1/November/2020



Dorte Jepsen  
Senior Manager  
Grundfos Holding A/S  
Poul Due Jensens Vej 7  
8850 Bjerringbro, Denmark

Manufacturer or person empowered to sign the EU declaration of conformity.

**Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana km. 37.500 Centro  
Industrial Garin  
1619 - Garin Pcia. de B.A.  
Tel.: +54-3327 414 444  
Fax: +54-3327 45 3190

**Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Tel.: +61-8-8461-4611  
Fax: +61-8-8340-0155

**Austria**

GRUNDFOS Pumpen Vertrieb  
Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Fax: +43-6246-883-30

**Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomsesteenweg 81-83  
B-2630 Aartselaar  
Tel.: +32-3-870 7300  
Fax: +32-3-870 7301

**Belarus**

Представительство ГРУНДФОС в  
Минске  
220125, Минск  
ул. Шаффарнянская, 11, оф. 56, БЦ  
«Порт»  
Тел.: +375 17 397 397 3  
+375 17 397 397 4  
Факс: +375 17 397 397 1  
E-mail: minsk@grundfos.com

**Bosnia and Herzegovina**

GRUNDFOS Sarajevo  
Zmaja od Bosne 7-7A  
BiH-71000 Sarajevo  
Tel.: +387 33 592 480  
Fax: +387 33 590 465  
www.ba.grundfos.com  
E-mail: grundfos@bih.net.ba

**Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo  
Branco, 630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Tel.: +55-11 4393 5533  
Fax: +55-11 4343 5015

**Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel.: +359 2 49 22 200  
Fax: +359 2 49 22 201  
E-mail: bulgaria@grundfos.bg

**Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Tel.: +1-905 829 9533  
Fax: +1-905 829 9512

**China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
10F The Hub, No. 33 Suhong Road  
Minhang District  
Shanghai 201106 PRC  
Tel.: +86 21 612 252 22  
Fax: +86 21 612 253 33

**Columbia**

GRUNDFOS Colombia S.A.S.  
Km 1.5 vía Siberia-Cota Conj. Potrero  
Chico,  
Parque Empresarial Arcos de Cota Bod.  
1A.  
Cota, Cundinamarca  
Tel.: +57(1)-2913444  
Fax: +57(1)-8764586

**Croatia**

GRUNDFOS CROATIA d.o.o.  
Buzinski prilaz 38, Buzin  
HR-1001 Zagreb  
Tel.: +385 1 6595 400  
Fax: +385 1 6595 499  
www.hr.grundfos.com

**Czech Republic**

GRUNDFOS Sales Czechia and Slovakia  
s.r.o.  
Čajkovského 21  
779 00 Olomouc  
Tel.: +420-585-716 111

**Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tel.: +45-87 50 50  
Fax: +45-87 50 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

**Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburri tee 92G  
11415 Tallinn  
Tel.: + 372 606 1690  
Fax: + 372 606 1691

**Finland**

OY GRUNDFOS Pumpum AB  
Trukkikuja 1  
FI-01360 Vantaa  
Tel.: +358-(0) 207 889 500

**France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnés  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tel.: +33-4 74 82 15 15  
Fax: +33-4 74 94 10 51

**Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Fax: +49-(0) 211 929 69-3799  
E-mail: infoservice@grundfos.de  
Service in Deutschland:  
kundendiensl@grundfos.de

**Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Tel.: +0030-210-66 83 400  
Fax: +0030-210-66 46 273

**Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor, Siu Wai Industrial  
Centre  
29-33 Wing Hong Street & 68 King Lam  
Street, Cheung Sha Wan  
Kowloon  
Tel.: +852-27861706 / 27861741  
Fax: +852-27858664

**Hungary**

GRUNDFOS Hungária Kft.  
Tópark u. 8  
H-2045 Törökbalint  
Tel.: +36-23 511 110  
Fax: +36-23 511 111

**India**

GRUNDFOS Pumps India Private  
Limited  
118 Old Mahabalipuram Road  
Thoraipakkam  
Chennai 600 097  
Tel.: +91-44 2496 6800

**Indonesia**

PT GRUNDFOS Pompa  
Graha Intirub Lt. 2 & 3  
Jln. Ciliilitan Besar No.454. Makasar,  
Jakarta Timur  
ID-Jakarta 13650  
Tel.: +62 21-469-51900  
Fax: +62 21-460 6910 / 460 6901

**Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Tel.: +353-1-4089 800  
Fax: +353-1-4089 830

**Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Fax: +39-02-95309290 / 95838461

**Japan**

GRUNDFOS Pumps K.K.  
1-2-3, Shin-Miyakoda, Kita-ku  
Hamamatsu  
431-2103 Japan  
Tel.: +81 53 428 4760  
Fax: +81 53 428 5005

**Korea**

GRUNDFOS Pumps Korea Ltd.  
6th Floor, Aju Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Tel.: +82-2-5317 600  
Fax: +82-2-5633 725

## Latvia

SAIA GRUNDFOS Pumps Latvia  
Deglava biznesa centrs  
Augusta Deglava ielā 60  
LV-1035, Riga,  
Tel.: + 371 714 9640, 7 149 641  
Fax: + 371 914 9646

## Lithuania

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel.: + 370 52 395 430  
Fax: + 370 52 395 431

## Malaysia

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguan Ut1/25  
Glenmarie Industrial Park  
40150 Shah Alam, Selangor  
Tel.: +60-3-5569 2922  
Fax: +60-3-5569 2866

## Mexico

Bombas GRUNDFOS de México  
S.A. de C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Tel.: +52-81-8144 4000  
Fax: +52-81-8144 4010

## Netherlands

GRUNDFOS Netherlands  
Veluwezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Fax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

## New Zealand

GRUNDFOS Pumps NZ Ltd.  
17 Beatrice Tinsley Crescent  
North Harbour Industrial Estate  
Albany, Auckland  
Tel.: +64-9-415 3240  
Fax: +64-9-415 3250

## Norway

GRUNDFOS Pumper A/S  
Strømsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tel.: +47-22 90 47 00  
Fax: +47-22 32 21 50

## Poland

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo k. Poznania  
PL-62-081 Przeźmierowo  
Tel.: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

## Portugal

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet de Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Fax: +351-21-440 76 90

## Romania

GRUNDFOS Pompe România SRL  
S-PARK BUSINESS CENTER, Clădirea  
A2, etaj 2  
Str. Tipografilor, Nr. 11-15, Sector 1, Cod  
013714  
Bucuresti, Romania  
Tel.: 004 021 2004 100  
E-mail: romania@grundfos.ro

## Russia

ООО Грундфос Россия  
ул. Школьная, 39-41  
Москва, RU-109544, Russia  
Тел. (+7) 495 564-88-00 (495) 737-30-00  
Факс (+7) 495 564 8811  
E-mail grundfos.moscow@grundfos.com

## Serbia

Grundfos Srbija d.o.o.  
Omladinskih brigada 90b  
11070 Novi Beograd  
Tel.: +381 11 2258 740  
Fax: +381 11 2281 769  
www.rs.grundfos.com

## Singapore

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Tel.: +65-6681 9688  
Faxax: +65-6681 9689

## Slovakia

GRUNDFOS s.r.o.  
Prievozská 4D 821 09 BRATISLAVA  
Tel.: +421 2 5020 1426  
sk.grundfos.com

## Slovenia

GRUNDFOS LJUBLJANA, d.o.o.  
Leskóškova 9e, 1122 Ljubljana  
Tel.: +386 (0) 1 568 06 10  
Fax: +386 (0)1 568 06 19  
E-mail: tehnika-si@grundfos.com

## South Africa

GRUNDFOS (PTY) LTD  
16 Lascelles Drive, Meadowbrook Estate  
1609 Germiston, Johannesburg  
Tel.: +(27) 10 248 6000  
Fax: +(27) 10 248 6002  
E-mail: lgradidge@grundfos.com

## Spain

Bombas GRUNDFOS España S.A.  
Camino de la Fuentecilla, s/n  
E-28110 Algete (Madrid)  
Tel.: +34-91-848 8800  
Fax: +34-91-628 0465

## Sweden

GRUNDFOS AB  
Box 333 (Lunnagårdsgatan 6)  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Fax: +46 31 331 94 60

## Switzerland

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-44-806 8111  
Fax: +41-44-806 8115

## Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Tel.: +886-4-2305 0868  
Fax: +886-4-2305 0878

## Thailand

GRUNDFOS (Thailand) Ltd.  
92 Chaloem Phrakiat Rama 9 Road  
Dokmai, Pravej, Bangkok 10250  
Tel.: +66-2-725 8999  
Fax: +66-2-725 8998

## Turkey

GRUNDFOS POMPA San. ve Tic. Ltd.  
Sti.  
Gebze Organize Sanayi Bölgesi  
İhsan dede Caddesi  
2. yol 200, Sokak No. 204  
41490 Gebze/ Kocaeli  
Tel.: +90 - 262-679 7979  
Fax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

## Ukraine

Бізнес Центр Свропа  
Столичне шосе, 103  
м. Київ, 03131, Україна  
Tel.: (+38 044) 237 04 00  
Fax: (+38 044) 237 04 01  
E-mail: ukraine@grundfos.com

## United Arab Emirates

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone, Dubai  
Tel.: +971 4 8815 166  
Fax: +971 4 8815 136

## United Kingdom

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 4TL  
Tel.: +44-1525-850000  
Fax: +44-1525-850011

## U.S.A.

GRUNDFOS Water Utility Head Quarters  
Brookshire, Texas 77423 USA

## Uzbekistan

Grundfos Tashkent, Uzbekistan  
The Representative Office of Grundfos  
Kazakhstan in Uzbekistan  
38a, Oybek street, Tashkent  
Tel.: (+998) 71 150 3290 / 71 150 3291  
Fax: (+998) 71 150 3292

## Revision Info

Last revised on 09-09-2020

be think innovate

---

<b>99802941 11.2020</b>
ECM 1299999

\*Trademarks displayed in this material, including but not limited to Grundfos, the Grundfos logo and 'be think innovate' are registered trademarks owned by The Grundfos Group. All rights reserved.

© 2020 Grundfos Holding A/S.  
all rights reserved.

**GRUNDFOS** 